

SLAT STABILIZER ASSEMBLY INSTRUCTIONS

NOTE: Slat stabilizers are only needed if placing your adjustable base on a wooden platform without the legs.

Step 1

Prepare for installation by raising the head panel to access the frame and slats.

Step 2


Using two (A) bolts and two (B) nuts, attach one (D) bracket to the side of the adjustable base. Repeat on the other side.

Step 3


Using four (C) screws, attach the (D) bracket to the slats. Repeat on the other side.

PARTS LIST:

- (A) Bolts x4
- (B) Nuts x4
- (C) Screws x8
- (D) Brackets x2



ATTENTION: Do not attach slat stabilizers to adjustable base head panel.



Read all instructions before assembling the adjustable base slat stabilizers. Before each usage or assembly, inspect the adjustable base for damaged hardware or missing parts. DO NOT use the adjustable base if any parts are missing or broken. If replacement parts and instructional literature are needed, contact the manufacturer at 800-517-7179. DO NOT substitute parts.